Dryer
Trockner
Sèchoir
Asciugatrice
Secadora
Wasdroger
Tørretumler

FP10756 FP10757

THE INSTRUCTION MANUAL CONTAINS IMPORTANT SAFETY INFORMATION. PLEASE READ AND FOLLOW THE INSTRUCTIONS.

Pre-use Precautions (Very Important)

1.Electrical Safety Electrical Safety Tips:

1.The grounding terminal of the socket must be reliably grounded. It is recommended to install a leakage protector. Do not use if the socket is not properly grounded.

2.Unplug the operation of the dryer, do not place flammable or metal objects on the dryer, and do not place heavy objects on the dryer. 3.Children should be kept at a distance and not allowed to touch the dryer to prevent accidents.

4.When the dryer is in normal use, the power cord plug should be connected to a dedicated socket. Do not share it with other high-power appliances to avoid overloading the circuit. Do not pull the power cord or use wet hands to insert or remove the plug.

5.If the power cord is damaged, it must be replaced by professional people to avoid danger.

6.It is strictly forbidden to operate the dryer on top of packaging foam, plastic bags, etc. Make sure the air inlet and outlet are not blocked by foam.

7.Allow the dryer exterior to the exterior of the dryer to dry, clean it with a damp cloth, and do not use chemical solvents or other corrosive cleaners to avoid damage to the dryer.

8.The dryer dryer cannot be used if chemicals are used to clean the clothes.

9.Clothes that contain metal accessories such as buttons or zippers, or fluffy clothes, should be properly prevent gun flowing out of the dryer to prevent damage to the dryer and affecting the drying effect.

10.Do not add the exhaust vent to a flue that serves a combustion appliance or other exhaust.

3. Usage Requirements

1.Ensure a smooth ventilation: Strictly prohibit indoor heating placed in the dryer to dry. Clothes that are wrung by hand may contain a large amount of moisture, which will significantly reduce the drying efficiency. The dryer is not suitable for drying.

2.Before drying, carefully check the pockets of the clothes to ensure there are no hard objects such as coins, keys, or metal buttons, to avoid damage to the drum.

3.Fabric stickers, buttons, etc., and lace-like clothes made out before washing, should be placed in a mesh bag for drying.

4.Separate clothes: Do not mix wet and dry clothes. The dry clothes should not be dried in the dryer.

5.Do not dry textile fabrics, woolen clothes, or fabrics rubber in the dryer, as dryer and leather can be damaged, and woolen fabrics will shrink and harden after drying.

6.After each use, wipe the lint filter and the inner wall of the drum with a damp cloth to remove residual lint.

7.Do not dry the clothes of the same or similar texture in one session.

8.Do not dry clothes that have been sprayed with pesticides, not suitable for tumble drying, hang drying, flat drying, flat drying, or air drying.

9.Do not dry clothes that are soaked in the leather of the machine. Leather can be damaged by the high temperature and friction of the dryer, resulting in irreversible damage to the leather, which is a normal phenomenon.

Installation

The dryer should be installed on a level and sturdy floor, safe, or dedicated island. When installing the dryer, it should be kept 10-15 cm away from the wall to ensure ventilation.

1.Install the dryer in a well-ventilated area, and do not place it in a small space. The dryer is equipped with a condenser, but it is still recommended to be greater than 100 cubic meters. If the installation space is too small, it may affect the drying effect.

1.Hard Pipe Installation

Install the exhaust of the exhaust outlet connector as needed and connect it to the dryer.

2.Install the clothes dryer horizontally

1.Place the dryer on a flat surface and level it with the four feet. 2.Adjust the height of the feet to ensure the dryer is stable and does not shake.

3.Optional Installation Methods

1.Stacked Installation: Stack two dryers.

When using the dryer with a base, it must be installed on a flat, level, and sturdy base. The base must be installed on the ground or a sturdy platform. When installing the base, ensure that the connection between the stand and the wall is firmly secured to prevent the base from tilting or falling. It can hold a maximum of 80 kilograms between the stand and the wall to ensure stability and safety. The base can also be used as a shelf. It can hold a maximum of 80 kilograms between the stand and the wall (the stand is not included in the weight limit).

Daily Maintenance

To ensure the normal operation of the dryer, it is necessary to clean the exhaust and clean filters in a timely manner and also to clean the dryer drum and the inner wall of the drum regularly.

1.Cleaning the Exhaust Air Filter (Clean after each use)

1.Removing the Filter: Insert your hand into the drum and reach for the filter. Gently pull it out from the drum and place it on a flat surface.

2.Cleaning: Use a brush to remove lint from the filter, rinse it with water, and then thoroughly dry it before reinstalling.

3.Reinstallation: Ensure the filter is properly reinstalled in the drum to prevent lint from escaping and affecting the drying effect.

2.Cleaning the Exhaust Air Filter (Clean every ten uses)

1.Unplug and turn off the power of the dryer, pull out the water collection cassette and pull it toward its remover.

2.Remove the lint filter cover and use a vacuum cleaner to clean any lint or debris.

3.After cleaning, replace the filter cover back on the machine.

3.Machine Cleaning

Clean the exterior of the dryer or the exterior of the dryer with a damp cloth. Do not use chemical solvents or other corrosive cleaners to avoid damage to the dryer. Do not use chemicals to clean the clothes. Note: Do not use benzene, gasoline, or alcohol to clean the machine.

User Guide
Control Panel Instructions



Display Area

Button Area

Button	Function
Power	Press and hold the "Power" button for 0.5 to 1 second to turn the machine on/off.
Start/Stop	Press the "Start/Stop" button, and the dryer will start operating if conditions are met. Pressing the button will pause the dryer.
Reset	Pressing the "Reset" button will restore the dryer's program based on the condition of the clothing.
Time	Press the "Time" button to set the time (options: 30 minutes, 60 minutes, 1 hour, 2 hours, 3 hours, 4 hours, 5 hours, 6 hours). The remaining drying time based on the condition of the clothing.

Temperature	Press the "Temperature" button to select from four temperature settings: Low (40°C), Medium (50°C), High (60°C) or (°F). When the display shows — °C, it indicates the cold air drying function. Alternatively, you can adjust the temperature by pressing the "Temperature" button.

Display Area

Display	Function
Washer	When the washer is on, this picture is displayed and blinks in sync with the drum.
Clean	When the Dirty Sphere, it is a reminder to clean the filter.
Open	The light indicates that the door needs to be closed before the machine can start operating.
Shutdown	When any temperature and end of drying time of 30 minutes, it will enter shutdown mode. It applies to the clothing. Unlocked by the light.

Common Troubleshooting

If you encounter any issues with the dryer, please first check the power source before checking. In the following cases, sometimes it is not a machine failure, and you can troubleshoot it yourself. If the problem persists, please contact our customer service in a timely manner to repair it yourself.

Abnormal Phenomenon	Abnormal Cause	Solutions
Dryer has Stopped	Clothes are too dry, the dryer automatically stops to prevent damage to the clothes.	Once you pick up the clothes, the dryer will restart.
Dryer Stops Intermittently	The door is not closed properly, causing the door switch to be triggered.	Ensure the door is closed properly.
Clothes Not Dry Enough	The clothes are too wet, the load size is too large, the drying time is too short, the temperature is too low, the lint filter is clogged, the exhaust vent is blocked, the ventilation is poor, the room temperature is too low, the ambient humidity is too high, the clothes are too thick, the clothes are too tangled, the clothes are too few, the clothes are too dry, the clothes are too hot, the clothes are too cold, the clothes are too wet, the clothes are too dirty, the clothes are too light, the clothes are too heavy